

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS


For Models: KERC601HWH4, KERC601HBT4, KERC601HBL4
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	14		Cooktop, Ceran	28		Cover, Light
	LIT9752043	Installation Instructions		9753711CW	White		9751327	White
	LIT9753845	Use & Care Guide		9753711CC	Biscuit		9753320	Biscuit
	LIT9753027	Tech Sheet		9753711CB	Black		9751632	Black
	LIT9753028	Wiring Diagram	15	9781460	Rod, Small Element	30		Trim, Cooktop
	LIT9752686	Smart & Easy Guide	17	341196	Thermo Disc			Right
	LIT3191638	Tips, Safety Cook	18	9751800	Cover, Vent		9751275PW	White
	LIT9752775	Template, Anti-Tip	19	9751841	Gasket, Vent Cover		9751275PC	Biscuit
2	9781982	Gasket, Silicone	20		Backsplash		9751275PB	Black
4	9781459	Rod, Large Element		9781896GW	White			Left
5	9752892	Support, Element		9781896GC	Biscuit		9751276PW	White
6	9751629	Bracket, Pivot		9781896GB	Black		9751276PC	Biscuit
	9752003	Washer, Pivot	21	9751984	Bimetal		9751276PB	Black
7	9781553	Brace, Support	26	9751664	Cover, Backsplash	32		Glass, Backsplash
8	9753691	Clip, Support (4)	27		Endcap, Backsplash		9753910CW	White
9	9750969	Bumper, Rubber			Right		9753910CC	Biscuit
10	9781936	Hot Light		9781885FW	White		9753910CB	Black
11		Element, Surface		9781885FC	Biscuit	33	9780272	Screw, 10-16 x 1/2
	8272564	1500W - LR		9781885FB	Black	34	9780265	Screw, 10-16 x 3/8
	8272566	1800W - RF			Left	35	9751871	Screw, 10-16 x 1
	8272563	1000/2400W - LF		9781884FW	White			
	9753997	2200W - RR		9781884FC	Biscuit			
				9781884FB	Black			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: KERC601HWH4, KERC601HBT4, KERC601HBL4
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS


For Models:KERC601HWH4, KERC601HBT4, KERC601HBL4
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	9750676	Retainer, Glass
2		Trim, Door-Left
	9782003PW	White
	9782003PC	Biscuit
	9750631PB	Black
3		Trim, Door-Right
	9782004PW	White
	9782004PC	Biscuit
	9750632PB	Black
4		Trim, Door Bottom
	9781209PW	White
	9781209PC	Biscuit
	9781209PB	Black
5		Glass, Door
	9781627PW	White
	9781627PC	Biscuit
	9781627PB	Black
6		Vent, Door
	9753498GW	White
	9753498GC	Biscuit
	9753498GB	Black
	9781659	Gasket, Door Vent
	9781490	Seal, Door
		Vent Side
8		Handle, Door
	9780523PW	White
	9780523PC	Biscuit
	9780523PB	Black
9	9781449	Gasket, Door Glass
10	9750234	Hinge, Door R or L
11	9780265	Screw, 10-16 x 3/8
12	9781602	Frame, Window
13	9781586	Shield Door
14	9780771	Bumper, Rubber
15	9781593	Glass, Pyro Door
16	9781587	Seal, Glass
17	9781072	Screw, 10-24 x 3/8
18	9754006	Insulation
19	9781600GM	Liner, Door
20	9780583	Drawer & Roller
21	9750169	Bracket, Drawer
22	9780272	Screw, 10-16 x 1/2
24		Front, Drawer
	9750168PW	White
	9750168PC	Biscuit
	9750168PB	Black
25	423713	Support, Roller
	90296	Clip
28	9781502	Retainer, Glass(8)
29	9750693	Channel, Heat

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN CHASSIS PARTS

For Models: KERC601HWH4, KERC601HBT4, KERC601HBL4
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN CHASSIS PARTS


For Models: KERC601HWH4, KERC601HBT4, KERC601HBL4
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	9751350	Vent Box, Oven
2	9750514GM	Chassis, Front
3	9754011	Insulation, Wrap
4	9754000	Insulation, Rear
5	9781293GM	Oven Liner
6	3191649	Gasket Oven
7		Oven, Side L or R
	9781907PW	White
	9781907PC	Biscuit
8	9780664	Shield, Insulation
	9754009	Insulation, Side
9	9751789	Fan Duct, Side
10	9780265	Screw, 10–16 x 3/8
11	9752637	Burner Box
12	9750142	Oven Bottom
13	9751653	Duct, Top
14	9751060	Support, Fan
15	9750223	Drawer Rail, Left
	9750224	Drawer Rail, Right
16	9751020	Motor, Fan
17	9750147	Bottom Rail (2)
18	312701	Foot, (4)
19	9750149	Hinge, Door L or R
20	9780272	Screw, 10–16 x 1/2
21	9781904	Rail, Support
25	9753091	Vent, Tube
29	9781581	Door Switch
30	9751948	Relay, Dlb.
32	9780578	Button, Plug
33	9751808	Screw, 8–18 x 1

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KERC601HWH4, KERC601HBT4, KERC601HBL4
(White) (Biscuit) (Black)




Illus. No.	Part No.	DESCRIPTION
1	9750967	Element, Broil
2	9750213	Element, Bake
15	8935	Bulb, Oven Light
16	9781050	Socket, Oven Light
18	420104GM	Grill, Broiler
19	420101GM	Pan, Broiler
21	9750498	Rack, Standard
22	8053344	Sensor
23	3184533	Gasket, Lens
24	9781049	Lens, Oven Light
25	9781509	Screw, 8-32 x 3/8
26	340184	Screw, 10-16 x 1.5
27	9780265	Screw, 10-16 x 3/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REAR CHASSIS PARTS

For Models: KERC601HWH4, KERC601HBT4, KERC601HBL4
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	9751051	Back panel, Chassis
2	9752344	Box, Terminal
3	9751353	Panel, Rear Cover
4	9752345	Cover, Terminal Box
5	9751418	Bracket, Lock
6	9780265	Screw, 10-16 x 3/8
7	9751439	Oven Lock Assembly
8	9751590	Solenoid


Illus. No.	Part No.	DESCRIPTION
9	422222	Screw, 10-32 x 5/16
10	424238	Washer, #10 Lock
12	9751763	Switch, Interlock
13	9750887	Screw, 4-40 x 1
14	9750888	Nut
15	9750523	Rod, Lock
17	258076	Terminal Block
18	3169573	Ground Strap

Illus. No.	Part No.	DESCRIPTION
19	9751798	Vent Back, Oven
20	9753413	Block, Balance
21	9780272	Screw, 10-16 x 1/2
22	98884	Screw, 10-16 x 1
23	112432	Nut
24	690989	Screw, Ground 10-32 x 1/2

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models:KERC601HWH4, KERC601HBT4, KERC601HBL4
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	9781968CW	Console, Glass White
	9781968CC	Biscuit
	9781986CB	Black
	9781488	Spacer
2	9781981	Timer, Electronic
3	9780271	Screw, 8-18 x 1/2
4		End Cap (Right Hand)
	9751280FW	White
	9751280FC	Biscuit
	9751280FB	Black
		(Left Hand)
	9751279FW	White
	9751279FC	Biscuit
	9751279FB	Black
5	9780265	Screw, 10-16 x 3/8
8		Knobs, Control
	9750372FW	White
	9750372FC	Biscuit
	9750372FB	Black
21		Switch, Infinite
	9751364	1500W, LR
	9751363	1800W, RF
	9751758	1000-2400W, LF
	9751362	2200W, RR
22		Nut, Mounting
	422617	Single Element
	9751711	Dual Element
23	9781455	Seal, Switch (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Models:KERC601HWH4, KERC601HBT4, KERC601HBL4
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<u>SPLICING WIRES---25FT. LENGTH</u>			<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>			<u>CLEANER, COOKTOP</u>		
	242828	Wire, Black 12 Ga. 150°c		350930	White		9780196	Glass Cleaner
	242820	Wire, Black 14 Ga. 150°c		350956	Almond		3183488	Scraper
	242821	Wire, Blue 14 Ga. 150°c		261888	New Avocado	<u>ACCESSORIES</u>		
	242822	Wire, Brown 14 Ga. 150°c		261886	Coffee		241430	Foil, Aluminum Oven (18" X 25')
	242830	Wire, Brown 14 Ga. 200°c		261890	Harvest Gold	<u>LUBRICANT</u>		
	242823	Wire, Green 14 Ga. 150°c		285006	Superior Black		261582	Grease
	242824	Wire, Orange 14 Ga. 150°c		206922	Primer (White)	<u>ANTI-TIP KIT</u>		
	242829	Wire, Red 12 Ga. 150°c		4392901	Biscuit		9751745	Anti-Tip Kit
	242825	Wire, Red 14 Ga. 150°c	<u>PAINT, BULK (1 qt.)</u>			<u>WIRING HARNESS PARTS</u>		
	242831	Wire, Red 14 Ga. 200°c		799344	White (Uncut)		9752954	Harness, Wire (Main Harness)
	242826	Wire, White 14 Ga. 150°c		978883	Almond (Uncut)		9781932	Harness, Wire (Cooktop)
	242827	Wire, Yellow 14 Ga. 150°c		261891	Harvest Gold (Uncut)		9781767	Harness, Wire (Ceran)
	242832	Wire, Yellow 14 Ga. 200°c		4392900	Biscuit		9750376	Harness, Wire (Oven Door)
<u>PAINT, TOUCH-UP (1/2oz.)</u>			<u>REFINISHING MATERIAL</u>				9781655	L2 - Electric
	72017	White		799832	Kit, Porcelain Repair (White)		20082084	Tie, Wire
	72107	Almond		242756	Touch-Up Self-Clean (1/2 Pt.)		9781769	Harness, Wire (Front Console)
	72109	New Avocado	<u>INSULATION</u>				690989	Screw, Ground
	72108	Coffee		9754011	Insulation, Wrap		3196520	Clip, Wire
	72110	Harvest Gold		9754000	Insulation, Rear		9751868	Grommet, Harness
	**511873	White Porcelain (2 Oz.)					313660	Clip, Ground Wire
	4392899	Biscuit					98997	Clip, Wire

* * **NOTE:** The spray paint is
Porcelain; All Other Panels are
Painted Surfaces.